Manuel d'utilisation

Français









© 2009 Peter Salzgeber, FSHeli.ch

Manuel d'utilisation

Français

Contenu

Page

- Préface par Peter Salzgeber Installation
- 4. Présentation des modèles
- 5. Avant de partir...
 - ...réglage conseillé
 - ...réglage du joystick conseillé
- 6. Démarrage

Premiers pas dans le cockpit...

- ...ce qu'il fau encore savoir
- 7. Autres clicks et tricks Clickspots
- 8. Carte du cockpit
- 9. Lama démarrage de la turbine
- 11. "Pas-General": le réglage des pales du Lama
- 12. Les scéneries
- 13. Missions pour Acceleration-Pack
- 15. Tableau des donnés techniques
- 16. Checklists
- 23. Remerciements et aide

Bienvenue sur FSHELI.CH Sud Aviation Lama pour FSX

Préface par Peter Salzgeber

Mon but était de créer un hélicoptère aussi réaliste que possible pour un simulateur de vol avec lequel il est possible non seulement de voler mais également de faire des travaux typiques à celui-ci.

Avec l'aimable collaboration d'employés de diverses entreprises d'hélicoptères, de pilotes et de mécaniciens, il m'a été possible de mener à bien ce projet, toujours dans les limites des possibilités offert par le simulateur Microsoft. Une simulation 100% réaliste n'est malheureusement pas possible car les limites de Microsoft sont ce quel sont. Une Alouette II n'est vraiment pas un Jet-Ranger...

J'espère que vous aurez beaucoup de plaisir avec mon Lama pour FSX.



Avant de partir

...l' installation

Fermez tout les applications avant de démarrer l'installation du Lama et faite attention, que votre disque dur n'est pas trop fragmenté. Sous Windows 98/ME/ ou Windows NT4.0/2000 ou Windows XP, le Lama - setup se démarre automatiquement, si vous n'avez pas fermé la fonction auto-éxécuter de Windows (seulement version CD). Sous Windows XP, il faut se registrer sous administrateur. Suivez les fenêtres et cliquez oui, si désire.

S.v.p, installez d'abord le Flight Simulator X Service Pack 1. Vous le trouvez ici: http://www.fsinsider.com/downloads/Pages/FlightSimulatorXServicePack1.aspx

Nous vous conseillons aussi l'utilisage du Flight Simulator X Service Pack 2 ou du *Acceleration-Pack* pour FSX. http://www.fsinsider.com/downloads/Pages/FlightSimulatorXServicePack2.aspx

...Choisir les modèles

Choisez dans le menu "appareil" le Lama X. Vous avez le choix entre 11 configurations et 9 couleurs.

Metez le crochet "Voir toutes versions".

Chargez d'abord un appareil standard du FSX (p. ex. le JetRanger ou une Cessna), avant de charger le Lama X.

Comme ça vous etes sure d'avoir totes les fonctions des instruments du Lama X



...les modèles

	Standard Summer Equipment	Passengers with Summer-Equipment, Sling-Load for <i>Acceleration-Pack</i>	HB XPJ
	Heliskiing Winter Equipment	Passengers with Winter-Equipment, Sling-Load for <i>Acceleration-Pack</i>	
	SpectroLab	SpectroLab NightSun Search-light	
	Spray	Spray-Unit	
8m	Sling 8 Meter Standard	Event-Panel handled Sling-Load	0000
10.00	Sling 16 Meter Standard	Event-Panel handled Sling-Load	0000
	Winch	Event-Panel handled Winch-Load	Winch Cable Up / Down with Shift+E
· ·	Long-Line 50m Short-Line 16m	Event-Panel handled Sling-Load	Winch Cable Up / Down with Shift+E
X forest values	Winch ACP Acceleration Pack	Winch-Ops for <i>Acceleration-Pack</i> only	Flight Simulator
	Winter Equipment	Skids, Basket, Heliskiing-Equipment	



Avec Shift+3 vous appellez le "Event-Panel". Avec ce-lui vous régléz les charges.


Avec le commande "fumé" "i" vous démmarez le pulveriseur ou l'eau au Bamby-Bucket.


Pour voler avec des charges "vraies", vous avez la possibilité de le faire avec le Acceleration-Pack. Pour cette occasion, nous avons faite des missions d'éxercise. Plusieurs plus tard.




Au premier appel de l'Lama sous FSX, il faut confirmer, si vous voulez exécuter ce logiciel. Cliquez sur "Exécuter" et après sur "Oui". Il faut répeter ça pour toutes instruments entre sa315000.gau au sa315009.gau.

...réglages conseillées








Afin qu'il vous soit possible d'utiliser le LamaX de manière optimale, je vous conseil de faire les réglages suivants :

- Le réglage du réalisme dans le menu de l'avion devrait plutôt être sur moyen pour débutants, pour avancées sur 100%.
- Enclencher «Avion projet ombres» et «Phare d'atterrissage éclaire le sol» sous options – réglage – écran – avion.
 Régler la qualité des textures ainsi que les effet lumineux plutôt de manière élevé
- Régler la sensibilité de tous les axes du joystick de manière très sensible, la zone du zéro sur « 0 ». Avec un joystick de type « Microsoft..... » dans le menu « calibrer » régler les voies de manière courte. Les mouvements au stick doivent être très petits, car il s'agit bien d'un hélicoptère et non d'une gondole! ©

Conseil: utilisez FSUIPC 4.0 ou plus haute de Peter Dowson pour régler votre Joystick et les pédales plus précisément. Vous trouvez FSUIPC ici: http://www.schiratti.com/dowson.html Voyez ici les réglages conseillées:



Maintenat on va partir

Premiers pas dans le cockpit...



Maintenant vous êtes assis pour la première fois dans le cockpit de l' Alouette II. Nous parlons donc maintenant de la dimension 3D du cockpit. Il faut à présent effectuer les choses suivantes :

- Le zoom dans le cockpit virtuel donc être entre 0.30 et 0.40 afin d'avoir une vue optimale.
- Faisiez attention aux images dessous avec les click-spots des panels. Quand vous cliquez sur les click-spots, les fenêtres c'ouvre.
- SI vous utilisez un écran large, changez le réglage suivant dans le FSX.cfg sous%APPDATA%\Microsoft\FSX le réglage: [Display] WideViewAspect=True
- Un cockpit 2D conventionel n'existe pas dans la version FSX.

que faut il savoir en plus

Le frein du rotor peut être tiré (cliquer dessus), quand le moteur tourne au ralentis (levier de gaz blanc complètement en arrière ou tapez Ctrl+F1) quand le roteur principal tourne a < 175 RPM.

Le phare d'atterrissage ce déployé et s'allume en cliquant sur la touche "Landing Light".








Avec la touche "A"
vous povez
changer entre les
vues « Bubble»*,
« Radio-Stack » et
« Overhead ».
*(Dans le model
"Treuil" c'est la vue
de l'operateur du
treuil.)

Le levier blanc dans le pedestal (rouge = levier d'urgence, blanc = levier de gaz « throttle ») peut être bougé avec la souris.

Click-Spots dans le Cockpit



Cockpit-Map





- 1: Altimeter
- 2: Variometer
- 3: Attitude Indicator
- 4: Indicated Airspeed
- 5: Horizontal Situation
- 6: VOR 1
- 7: Radar Altimeter
- Pas General Indicator
- 1: Battery Temperature
- 2: Fuel Filter
- 3: Engine Chip
- 4: Pitot Heater
- 5: Master Warning
- 6: Turn Libelle
- 7: Generator
- 8: Fuel Pressure
- 9: Transmission Oil Press.
- 10: Transmission Oil Temp.

- A: Starter
- B: Micro Pump
- C: Stop Start
- D: Engine Oil Pressure
- E: Test Fuel Quantity
- Avionics Master
- Pitot Heater
- Position Lights
- Mission !
- Generator
- 6 Battery
- Strobes
- Nav. / GPS
- 1: Voltmeter
- VOILITIO
- 2: Clock
- 3: Fuel Low Warning < 3 Minutes
- 4: Fuel Quantity with Warninglight
- 5: T4 Temperature (EGT)
- 6+7: Engine Oil Temp + Engine Oil Press
- 8: Fuel Booster Pump
- 9: Starter Switch
- 10: Engine and Rotor RPM



Lama démarrage del a turbine

Dérive de l'appareil originel, seulement pour FSX

Voir les check-lists!

- 1. Interrupteur principale ON
- 2. Générateur ON
- 3. Feux anticollision ON
- 4. Levier blanc "gas/throttle" sur 0 (CTRL+F+)
- 5. Levier collective 0%
- 6. Pompe carburant ON (le feu « FUEL PRESS » éteindra)
- 7. relaisser le levier du frein du roteur.
- 8. Démarrez le moteur électrique sous la capuche rouge (fonctionne en détail plus tard)
 - → vous entendez le moteur, la lampe verte est allumé
- 9. Démarrez l'injection du carburant. Démarrer impérativement celle-ci avant que la lampe verte soit éteinte
- 10. La lampe jaune est allumée
- 11. Turbine tourne → Quand la lampe verre est éteinte, pousser le levier blanc "gas/throttle" sur 30%
- 12. contrôler la température (T4 et huillle)
- 13. retirer le Levier blanc "gas/throttle" a 0%, le roteur commence a tourner
- 14. Synchronisation de la turbine avec le roteur
- 15. Levier blanc "gas/throttle" lentement vers 50%
- 16. Collective toujours a 0%, le roteur tourne a < 100%
- 17. Radio / Avionique ON
- 18. Com 1 sur ATIS (RADIO)
- 19. Stabiliser pour une minute
- 20. Levier blanc "gas/throttle" sur 100%
- 21. le roteur tourne a 100%, le feu « LIMITE » éteindra
- 22. Stabilizer pour une minute

Step 1 - 2 - 3



Step 4 - 5



Step 6



Step 8



Starter On



Micro-Pump On



Run Up



Synchronisation



Lama arrèt de la turbine

Dérive de l'appareil originel, seulement pour FSX Voir les checklists.

- 1. Collective à 0%
- 2. Lévier du gaz (blanc) à 0 (tout arrière)
- 3. Laisser une minute tourner au vide
- 4. Controller les temperatures (T4 et huille)
- 5. Cliquer sûr STOP (cursor "-") et surveiller les temperatures.
- 6. Eteindre la pompe d'essence
- 7. Tirer le frein du roteur quand le roteur est < 175 rpm
- 8. Tout le interrupteurs OFF

"Pas-General": le réglage des pales

L'indication de l'angle des pales est très importante sur le Lama. Dépasser la ligne rouge, aura une décélération du roteur. Le "stall" subséquent laisse tomber l'appareil très vite. En altitude baisse manquera la possibilité du reprendre l'appareil. En poussant le levier collectif en bas, la vitesse correcte du roteur peut être reprise. Quand la lampe de prestation est éteinte, le collective peut être retiré lentement.









Les scéneries

Déscription

Compris dans la version pour FSX sont les scéneries de la base de Air-Zermatt à Zermatt et Raron, le village de Zermatt et les cabannes de Hörnligrat, Schönbiel, Monterosa, Topali et Hollandia faites par Michael Röthlisberger.





Missions pour Acceleration-Pack

Déscription

Pour Acceleration-Pack, il y à 6 missions d'éxercise pour le Lama X (elles fonctionnent que avec le Acceleration-Pack pour FSX et sont installées seulement, si le Acceleration-Pack pour FSX est installé sur votre système!)

- Exercise charges à Raron et Zermatt Sur les bases, vous trouvez des objets pour les accrocher à l'helico et les voler à une place, la quell vous choisez vous-même. Vous pouvez choisir entre des câbles à 8 ou 16 metres.
- Exercise du sauvetage avec câble fixe au Mont Cervin Décollez à la base de Zermatt et volez vers la cabanne du Mont Cervin pour accrocher le sauveteur au câble de 16 metres et pour sauver une personne du Mont Cervin
- Exercise du sauvetage avec le treuil au Mont Cervin Décollez à cote de la cabanne du Mont Cervin et sauvez une personne du Mont Cervin.

Pour être bien préparé pour les missions avec le Lama, nous vous conseillons de voler les missions « Sling-Load-Tutorial » avec la EH101 du Acceleration-Pack pour FSX!







Sauvetage spectaculaire au Mont Cervin.

Les missions sont que des éxercises pour apprendre de faire des vols avec des charges et des sauvetages avec le Lama. Il n'y a pas des "skills" et des buts, qu'il faut accomplir. Il n'y a pas des medailles de gagner. Laissez libre votre phantasie! Volez les objets d'une place à l'autre et peut-être aussi retour – tout comme vous désirez.

Solution des problèmes avec les missions / scéneries:

Si vous avez installé la fausse scénerie, vos pouvez la changer tout les temps avec l'util "Lamax Scenery Settings" sur votre burau.

- J'ai pas des LamaX- missions: le « Acceleration Pack pour FSX » doit être installé.
- Je ne vois pas les scéneries: les scéneries doivent être annoncées sous « World/Scenery Library ».
- Je ne vois pas le train Zermatt-Gotthard: ce-lui là est seulement installé avec la scénerie "advanced".
- Le Lama ou la scénerie n'est pas à la bonne plâce au début d'une mission: installer la bonne scénerie : (Default ouAdvanced Meshes pour CHproX etc.)
- Les objets ne sont pas visibles: (p. ex. Zermatt Sling-Load): charger le vol de nouveau. (Ctrl+è)
- Le Lama es de-sous la plattforme ou la turbine est en mârche (Zermatt Sling-Rescue): charger le vol de nouveau. (Ctrl+è)

Les missions et scéneries sont optimizées d'utilizer avec Switzerland Professional X de FlyLogic.






Le "Acceleration-Pack pour FSX" et "Switzerland Professional X" sont disponible dans votre magasin préferé ou sous www.flylogicsoftware.com www.simmarket.com www.simmarket.com


Les missions sont "open-source", vous ètes libre de les modifier avec le « Object-Placement-Tool » ou de créer des nouvelles missions selon vos désires pour votre l'utilisation personelle. Les fichiers dans cette logiciel sont protégées (copyrigt).

Object Placement Tool

Le « Object-Placement-Tool » est compris dans le SDK du Acceleration-Pack pour FSX. Vous trouvez plusieurs informations dans le SDK sous "Mission Creation Kit".

Après avoir insttallé correctement, vous trouvez le Object-Placement-Tool sous le menu « Tools/ Object-Placement-Tool »





Sur le site http://www.fsinsider.com vous trouvez plusieurs informations et liens.

S.v.p., avez comprenance, que pour nous, il ne sera pas possible de vous donner aucun support conçernant le Object-Placement-Tool. Il est documenté de manière suffisante dans le SDK et sur l'internet.

Données techniques S.N.C.A.S.E. / Sud Aviation Lama

Décignistion des types SNCASE / Sud Avietien / Agreematicle			
Désigniation des types SNCASE / Sud Aviation / Aerospatiale			
	SE3130 / SA313B	SA318C	SA315B
	Alouette II	Alouette II	Lama
Sitzzahl Nombre de places Seating	1 + 4	1 + 4	1 + 4
Hauptrotor-Durchmesser Diamètre du roteur Rotor-Diameter	10,200 m	10,200 m	11,020 m
Länge Longueur Lenght	12,050 m	12,100 m	12,919 m
Höhe Hauteur Height	2,750 m	2,750 m	3,090 m
Breite Largeur Width	2,080 m	2,380 m	2,380 m
Maximales Startgewicht Masse Max MTOW	1600 kg	1650 kg	1950 kg
Aussenlast Charge à l'élingue Sling Load	500 kg	600 kg	1135 kg
Max. Geschwindigkeit	185 km/h	205 km/h	210 km/h
Vitesse MAX VNE	100 kts	111 kts	113 kts
Max. Reisegeschwindigkeit	170 km/h	180 km/h	192 km/h
Vitesse de croisière Cruising Speed	92 kts	97 kts	103 kts
Turbine Turbomeca Typ Moteur Turboméca Engine Turbomeca	Artouste IIC / IIC5	Astazou IIA / IIA2	Artouste IIIB / IIIB1
Leistung Thermisch	530 ch	530 ch	870 ch
Puissance thermique Thermal Power	390 kW	390 kW	640 kW
Maximale Dauerleistung	360 ch	480 ch	550 ch
Puissance maximum continue Maximum Continuous Power	265 kW	353 kW	405 kW


FSHeli.ch Lama CHECKLISTS

for Flight Simulator use only!

WALK AROUND

WA	ALK AROUND	
MA	IN TANK FUEL DRAIN:	
1.	FUEL CIRCUIT BREAKERS	OUT
2.	BATTERY SWITCH	ON
3.	FUEL VALVE SWITCH	OFF
4.	FUEL DRAIN BUTTON	PRESS
5.	FUEL VALVE SWITCH	ON
6.	BATTERY SWITCH	OFF
	R FRAME FUEL FILTER DRAIN:	
	BATTERY SWITCH	
8.	FUEL CIRCUIT BREAKER (one only)	IN
9.	CAUTION LIGHTS CB	IN
	A/F FUEL FILTER DRAIN VALVE	
	A/F FILTER TEST SWITCH	
	FUEL FILTER DRAIN VALVE	
	FUEL CIRCUIT BREAKERS	
	CAUTION LIGHTS CIRCUIT BREAKERS	
15.	BATTERY SWITCH	OFF
NO		
	MAIN ROTOR BLADE	
	PITOT	
	BATT COMPARTMENT, TAXI & LANDING LTS	
19.	EXTERNAL POWER DOOR	SECURE

20. CABIN FRONT GENERAL (Windshield, Air Inlets)...... CHECK



FUSELAGE, RH SIDE	
21. RIGHT STATIC PORT	FREE
22. CABIN DOORS, WINDOWS	
23. LANDING GEAR	
24. CABIN ROOF, TRANSM. COVER	
25. HYDRAULIC RESERVOIR OIL LEVEL	
26. HYDRAULIC SYSTEM FILTER	
27. HYDRAULIC SERVO ACTUATORS	
28. MR TRANSMISSION OIL LEVEL	
29. MR TRANSMISSION COMPARTEMENT	
30. DRAG PIN	
31. ENGINE AIR INLET	
32. ENGINE COMPARTMENT RH SIDE	
33. TAIL ROTOR DRIVESHAFT	
34. OVERHEAT PAINT STRIPS	
35. THROTTLE FUEL CONTROLL LINKAGE	
36. GENERATOR COOLING SCOOP	
37. EXHAUST COVER	
38. FUEL FILTER CAP	
39. ENGINE OIL TANK	
40. ACCESS DOORS	
REAR FUSELAGE, RH SIDE	
REAR FUSELAGE, RH SIDE 41. TAILROTOR DRIVESHAFT COVER	CONDITION
41. TAILROTOR DRIVESHAFT COVER	CONDITION
41. TAILROTOR DRIVESHAFT COVER	CONDITION
41. TAILROTOR DRIVESHAFT COVER	CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE	CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN	CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT TAIL ROTOR 48. TAIL ROTOR GEAR BOX CONDITI	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT TAIL ROTOR 48. TAIL ROTOR GEAR BOX CONDITI 49. PITCH LINKS, BOLTS, SECURING	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT TAIL ROTOR 48. TAIL ROTOR GEAR BOX CONDITI 49. PITCH LINKS, BOLTS, SECURING	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT TAIL ROTOR 48. TAIL ROTOR GEAR BOX CONDITI 49. PITCH LINKS, BOLTS, SECURING 50. TAIL ROTOR	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION ON, OIL LEVEL CHECK CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT 48. TAIL ROTOR 48. TAIL ROTOR GEAR BOX CONDITI 49. PITCH LINKS, BOLTS, SECURING 50. TAIL ROTOR REAR FUSELAGE, LH SIDE	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CHECK CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT TAIL ROTOR 48. TAIL ROTOR GEAR BOX CONDITI 49. PITCH LINKS, BOLTS, SECURING 50. TAIL ROTOR REAR FUSELAGE, LH SIDE 51. TAILBOOM	CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT 48. TAIL ROTOR GEAR BOX 48. TAIL ROTOR GEAR BOX 50. TAIL ROTOR REAR FUSELAGE, LH SIDE 51. TAILBOOM 52. HORIZONTAL STABILIZER, POSITION LIGHT	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CHECK CHECK CONDITION CONDITION CONDITION
41. TAILROTOR DRIVESHAFT COVER 42. TAILBOOM RIGHT 43. HORIZONTAL STABILIZER, POSITION LIGHTS 44. MAIN ROTOR BLADE VERTICAL FIN 45. TAIL ROTOR GUARD 46. ANTI COLLISION LIGHT 47. AFT POSITION LIGHT 48. TAIL ROTOR GEAR BOX CONDITI 49. PITCH LINKS, BOLTS, SECURING 50. TAIL ROTOR REAR FUSELAGE, LH SIDE 51. TAILBOOM 52. HORIZONTAL STABILIZER, POSITION LIGHT 53. BAGGAGE COMPARTEMENT CHECK, VE	CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION CONDITION ON, OIL LEVEL CHECK CONDITION CONDITION CONDITION RIFY LOADING

FUSELAGE LH SIDE	
56. EXHAUST COVER	REMOVE
57. ENGINE COMPARTMENT LH SIDE	CONDITION
58. GOVERNOR LINKAGE	CHECK
59. ENGINE ANTI ICE LINKAGE / VALVE	CHECK
60. ENGINE AIR INLET	CLEAR & CONDITION
61. MR TRANSMISSION COMPARTEMENT	CONDITION
62. HYDRAULIC SERVO ACTUATORS	CONDITION
63. ACCESS DOORS	SECURE
ROTOR	
64. ROTOR HEAD, BOLTS, SECURING	CHECK
65. ROTOR BLADES	CHECK
66. PITCH LINKS	CHECK
67. SWASHPLATE	CHECK
68. MR TRANSMISSION	CHECK
69. CABIN ROOF, TRANSM. COVER	CONDITION
70. CABIN DOORS, WINDOWS	
71. LANDING GEAR	
72. LEFT STATIC PORT	FREE
73. ANTENNAS	
74. MAIN ROTOR BLADE	CONDITION
75. MAIN ROTOR TIE DOWN	
76. HELICOPTER GENERAL APPEARANCE	

FSHeli.ch Lama CHECKLISTS

for Flight Simulator use only!

PKI	EST/	ART	CHE	CK

1.	OUTSIDE CHECK	
2.	DOCUMENTS	
3.	ROTORBRAKE re	
4.	SEAT & PEDALS	ADJUSTED
5.	SAFETY BELTS (INCLUDING PAX)	
6.	CONTROLS	CHECK FREEDOM
7.	CYCLIC & COLLECTIVE	FRICTION SET
8.	COMPUTER	MAX. PITCH CHECKED
9.	ELECTRICAL SWITCHES, AVIONICS	OFF
10.	CIRCUIT BREAKERS	IN
11.	BATTERY	ON (OFF WITH GPU)
12.	FUEL QUANTITY	CHECKED
13.	FLIGHT INSTRUMENTS	SET, CHECKED
14.	CABIN HEATER	OFF
15.	HYDRAULIC	ON (PUSHED IN)
16.	FUEL SHUT-OFF	SECURED
EN	GINE START	
1.	FUEL LEVER	FULLY BACK (AND HELD)
2.	FUEL BOOST PUMP	ON (>20 SEC)
3.	WARNING LIGHTS	CHECKED
4.	STARTER	(VENT) T4 <150 °C, THEN START

CAUTION:

TURN STARTER OFF / VENT, IF:

- BATT. BELOW 14 VOLT
- T4 DOES NOT RISE
- T4 EXCEEDS YELLOW ARC
- DEMAR. LIGHT (GREEN) IS NOT OFF AFTER 45 SEC.
- ENGINE OIL PRESSURE DOES NOT RISE
- WARNING LIGHT BLOC. (RED) ILLUMINATES

OBSERVE RISE OF T4, VENTILATE TO CONTROL T4 IF NECESSARY.

5.	IDLE RPM 16'000 – 19'000 CHECK
6.	GENERATORON
7.	OIL PRESSURE CHECKED
8.	POSITION LIGHT/BEACON, ICS, HORIZON, AVIONICSON

ROTOR ENGAGEMENT, RUN UP

1	ROTOR CLEAR
2	 CYCLIC NEUTRAL
3	CLUTCHENGAGE in 35-45 sec (increase max. 2'000 RPM)
4	FUEL LEVER FULL ADVANCE (T4 rise max. 50 °C) RED LIGHT OUT
5	STARTER SWITCH CHECK, THEN SECURED

6.	CAUTION & WARNING LIGHTS OUT			
BRIEFING BEFORE DEPARTURE				
1.	DEPARTURE SECTOR			
2.	DEPARTURE IN HIGE / HOGE BRIEFED			
3.	EXPECTED LIMITATION VERIFIED			
4.	EMERGENCY			
СН	ECK BEFORE DEPARTURE			
1.	DOORS			
2.	AVIONICS, FLIGHT INSTRUMENTS SET			
3.	FUEL LEVER, ROTOR RPM FULL FORWARD, GREEN ARC			
4.	ENGINE GAUGES GREEN			
5.	FUEL QUANTITY CHECKED			
6.	CAUTION & WARNING LIGHTS OUT			
7.	FRICTION OFF			
HO'	VER-CHECK			
1.	ROTOR RPM GREEN ARC			
2.	POWER			
3.	WIND CHECKED			
4.	DEPARTURE SECTOR			
CLI	MB CHECK			
1.	ROTOR RPM GREEN ARC			
2.	POWER			
3.	AIRSPEED FOR CLIMB			
CR	UISE CHECK			
1.	ROTOR RPM GREEN ARC			
	POWER CHECKED			
	ALTIMETER SET			
	LANDING LIGHT OFF			
5.	FUEL, ENGINE, ELECTRIC SYSTEMS MONITOR			
BR	EFING FOR APPROACH			
1.	REKO (W-A-HI-BEL-U) COMPLETE			
2.	APPROACH, LANDING HIGE / HOGE CONSIDER			
	EMERGENCY, ESCAPE CHECKED			
4.	PERFORMANCE, LIMITATION LANDING YES / NO			

Ch	IECK FOR APPROACH
1. 2.	FUEL LEVER, ROTOR RPM FULL FORWARD, GREEN ARC ENGINE GAUGES GREEN
3.	FUEL QUANTITY CHECKED
4.	CAUTION & WARNING LIGHTSOUT
5.	WIND CHECKED
FII	NAL CHECK
1.	SAFETY WINDOW (50 KMH / < 500 FPM) CHECKED
2.	POWER VS SPEED CHECKED
3.	DECISION LAND, OR GO AROUND
SH	IUT DOWN CHECK
1.	FRICTION (COLLECTIVE & CYCLIC)
2.	FUEL LEVER FULL DETENT
3.	FUEL BOOST PUMP OFF
4.	COM FREQUENCYCHECK 121.50
5.	POSITION LIGHT / BEACON, AVIONICS OFF
6.	ROTORBRAKE AT NR < 175 RPM, SET BLADE 12 O'CLOCK
7.	STARTER OFF
	CAUTION:
-	WATCH T4 DECREASING, VENTILATE IF NECESSARY
8.	BATTERY, GENERATOR OFF
PC	OST FLIGHT CHECK
1.	OIL LEVELS CHECK
2.	WINDSHIELD & COCKPIT CLEAN
3.	ROTOR SECURING, PROTECTIVE COVERS INSTALL

FSHeli.ch Lama CHECKLISTS

for Flight Simulator use only!

Short Check List

PRESTART

5. OUTSIDE CHECK COMPLETE 6. DOCUMENTS ON BORD 7. ROTORBRAKE released,12 o'clock 8. SEAT & PEDALS ADJUSTED 9. CONTROLS CHECK 10.CYCLIC & COLLECTIVE FRICT. 11.COMPUTER MAX. PITCH 12.ELECTR. SW., AVIONICS OFF 13.CIRCUIT BREAKERS IN 14.BATTERY 15.FUEL QUANTITY CHECKED 16.FLIGHT INSTRUMENTS CHECK 17.CABIN HEATER OFF ON (IN) 18.HYDRAULIC 19. FUEL SHUT OFF SECURED CLIMB CHECK

ENGINE START

1. ROTOR

1.	FUEL LEVER	FULLY BACK
2.	BOOST PUMP	ON >20"
3.	WARNING LIGTHS	CHECK
4.	STARTER	T4 >150°C
5.	OIL PRESSURE	CHECKED
6.	GENERATOR	ON
7.	LIGHTS, AVIONICS	ON

ROTOR ENGAGEMENT, RUN

2.	CYCLIC	NEUTRAL
3.	CLUTCH	ENGAGE
4.	FUEL LEVER	FULL FORWARD
5.	STARTER SWI	TCH CHECK
6.	CAUTION & WA	ARNING LT
	CHECK	

CLEAR

BRIEFING BEFORE DEPARTURE

1.	DEPARTURE	SECTOR	CHECK
2.	DEPARTURE	IN HIG	iE/HOGE

3. EXPECTED LIMITATION CHECK

4. EMERGENCY BRIEFED

CHECK BEFORE DEPARTURE

8.	DOORS	CLC	SED
9.	AVIONICS, FLIGHT INS	STR.	CHK
10.	FUEL LEVER, RPM	CHEC	CKED
11.	ENGINE GAUGES	CHEC	CKED
12.	FUEL QUANTITY	CHEC	CKED
13.	.CAUTION & WARNING	LT	OUT
14.	.FRICTION		OFF

HOVER-CHECK

1.	ROTOR RPM	GREEN ARC
2.	POWER	CHECKED
3.	WIND	CHECKED
4.	DEPARTURE	SECTOR CLEAR

1.	ROTOR RPM	GREEN ARC
2.	POWER	CHECKED
3.	AIRSPEED	FOR CLIMB

CRUISE CHECK

1.	ROTOR RPM	GREEN ARC
2.	POWER	CHECKED
3.	ALTIMETER	SET
4.	FUEL, ENGINE,	ELECTR. CHA

BRIEFING FOR APPROACH

1.	REKO	W-A-HI-BEL-U
2.	APPR., LANDING	HIGE / HOGE
3.	EMERGENCY, ESC	CAPE CHK
4.	PERFORM, LIMIT.	LDG YES / NO

CHECK FOR APPROACH

1.	FUEL LEVER, RPM	CHEC	CKED
2.	ENGINE GAUGES	CHEC	CKED
3.	FUEL QUANTITY	CHEC	CKED
4.	CAUTION & WARNING	LT	OUT
5.	WIND	CHEC	CKED

FINAL CHECK

4. SAFETY WINDOW (50 KMH/<

5. POWER VS SPEED CHECKED

6. DECISION LAND/GO-AROUND

SHUT DOWN CHECK

1 EDICTION

Ι.	FRICTION		SEI
2.	FUEL LEVER	FULL	IDLE
3.	FUEL BOOST PUMP		OFF
4.	LIGHTS, AVIONICS		OFF
5.	ROTORBRAKE	AT NR	<175
6.	STARTER		OFF
7.	BATTERY, GENERAT	OR	OFF

CET

POST FLIGHT

1.	OIL LEVELS	CHECK
2.	COCKPIT, WINDSHIELD	CLEAN
3.	COVERS, SECURING	AS REC

FSHeli.ch Lama Credits

Merci à tous ceux qui me permet d'avoir un tel projet. En particulier

Michael Röthlisberger, scénereies à couper le souffle

Monika Röthlisberger, traduction manuel anglais

Frank Picot-Pioz, traduction manuel français

Philipp Steinger, Air-Zermatt, détails techniques, photos, beta-testing

et tout l'équipe de l'Air-Zermatt pour le soutien

tout les beta-testers

Support et mises à jour

Sur notre site http://www.helicosim.com , vous trouvez de l'aide pour des problèmes.